



Handlebar Raise Adapters

CC-LE001-xx

Indian Scout 60, Indian Scout, Indian Scout Bobber

2015 and later

Suggested installation time: 30 minutes

Package Content:

- (2) Raised Mounts
- (4) Bolts
- (4) Conical Spring Washers

Tools Suggested:

Socket Set with Ratchet

Please read and understand the entire instructions before starting installation!

In order to protect you and others from possible injury, damage or loss, please make sure you have the necessary skills and tools to install this product and pay close attention to these instructions!

Installation:

1. Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.
2. Check the package content. If there are any parts missing or damaged, call the vendor.
3. Remove all four handlebar bolts holding the instrument cluster and put aside. They won't be re-used.
Attention: Have somebody help you holding the handlebars.
4. Lift handlebars out of upper triple clamp.
5. Insert left and right raised mount into triple clamp.
6. Insert handlebars into raised mounts and fasten assembly with new bolts.
Attention: The conical spring washers should be directed with the tip facing the bolt head and the opening facing the raised mount.
7. Torque bolts to 35 Nm.
8. Check bolts after 30 miles / 50 km and re-torque, if necessary.

Contact:

Cruiser-Center GmbH
Dieselstrasse 59
63165 Mühlheim am Main
Germany

Phone +49 – 6108 – 79934-0
Fax +49 – 6108 – 79934-29
info@cruiser-center.de
www.cruiser-center.de